DTM Fulcrum Switch Manager

For DTMs not installed in a COB, the switch manager software must be disabled.

To disable the Fulcrum switch manager

Log into the DTM

Execute fw_setenv nocm 1

Execute systemctl disable fmd

Reboot DTM

To reenable the Fulcrum switch manager

Log into the DTM

Execute fw_setenv nocm

Execute systemctl enable fmd

Reboot DTM