

V&V Setup on lat-hobbit4

- Login to lat-hobbit4 as user "glast" and create the following terminals with the working directory being ~glast/work/licos:
 - ProxyManager
 - ScriptEngine
 - StripChart
 - AlarmHandler
 - TelemetryTable

- In the ProxyManager terminal enter:

```
$ONLINE_ROOT/LICOS_ETC/start/runProxies.csh --vscip lat-elf21 --config vsc.cfg
```

- In the ScriptEngine terminal enter:

```
$ONLINE_ROOT/LICOS_ETC/start/cvt.csh localhost vsc.cfg
```

And verify that there are no errors in either \$LICOS_LOG/cvt.log or \$LICOS_LOG/cvt_db.log.
After that enter the following:

```
$ONLINE_ROOT/LICOS_ETC/start/scriptEngine.csh --config scriptEngine.cfg --server lat-elf21 --vscConfig  
vsc.cfg --scriptOpts $ONLINE_ROOT/LICOS_Config/opts/LatPowerOpts.cfg
```

- In the StripChart terminal enter:

```
$ONLINE_ROOT/LICOS_ETC/start/stripchart.csh --config $ONLINE_ROOT/LICOS_ETC/config/stripChart.cfg --  
vscConfig vsc.cfg --cvtHost localhost
```

- In the AlarmHandler terminal enter:

```
$ONLINE_ROOT/LICOS_ETC/start/alarmHandler.csh --config alarm.cfg --vscConfig vsc.cfg --cvtHost localhost  
--noPopAlarm
```

- In the TelemetryTable terminal enter:

```
$ONLINE_ROOT/LICOS_ETC/start/telemetryTable.csh --config $ONLINE_ROOT/LICOS_ETC/config  
/LAT_TLM_PKTMNEM_B0-6-1_abrv.cfg --vscConfig vsc.cfg --cvtHost localhost
```