

# Checking COB Status

COB status can be checked by looking at the front panel LCD or using SDK software tools.

To use the software tools, be sure the [SDK is installed](#) and [present in your current environment](#).

Your shelf manager must be already be [configured](#) for the network.

Execute the following command to see the status of all COBs installed in the shelf:

```
cob\_dump <shelf_manager_ip> --all
```

For more details, see pages 18 and 21 of this workshop presentation:

[RPT\\_Workshop\\_Shelf Installation\\_Networking\\_and\\_Administration.pptx](#)