

# Hardware FAQ

[How much memory does an RCE have?](#)

[How do I configure a shelf manager?](#)

[How do I set the shelf name?](#)

[How do I install a COB?](#)

[How do I check the COB status?](#)

[How do I power cycle a COB?](#)

[How do I install an RTM?](#)

[What is an RCE?](#)

[What is a DPM?](#)

[What is a DTM?](#)

[What is an RTM?](#)

[What is a COB?](#)

[What do the DIP switches do?](#)