

# Step-by-step to power on an ATCA shelf and COB board sdf

- [Power On ATCA shelf](#)
- [Power On COB board](#)

## Power On ATCA shelf

connecting the power cable, and the ATCA shelf will run with the default setup.

need to turn the cooling fan to lower speed to reduce noise

## Power On COB board

installed the COB board, COB-41, to the **4th** slot of this crate.