

Printing to the LCLSLOG from EPICS displays

Use the middle mouse button and click in the margins of the window to be printed.

Select Print... from the pop-up menu.

This opens a print dialog box where you must select **lclslog** from the list of printers on the Printer button.

Click ok and the print is sent to the eLog.