

Connecting to an IOC Console Port

Connecting to a CPU Serial Port

Cables

Directly from a Linux PC

SLAC Linux has restrictions for accessing the serial port and so special access must be requested in order to use the serial port of a linux-host without sudo privilege. On the SLAC Linux systems, a number of devices are associated with the "console". The user logged in at the console automatically gains access to these devices as long as he or she is logged into that machine. Unix-admin can add the serial port to this set of devices for your machines. Please note that the serial port is not added to the list of "console" devices as standard practice and so you will need to send email to Unix-admin to request such access.

If permissions are set appropriately, then you should be able to connect to **ttyS0** on your linux-host by typing the following from the shell:

```
minicom
```

Troubleshooting

If you are unable to connect to the serial port **ttyS0** on your linux-host (remember you can't do this via ssh), please do the following:

1) Check the file **/etc/security/console.perms** on linux-host you are requesting console access to and verify that the following two lines are included. The permissions listed are key.

```
<serial>=/dev/ttyS<01>  
<console> 0660 <serial> 0660 root.uucp
```

2) Check to see that you own the serial ports **ttyS0** and **ttyS1**. You can do this from the Unix shell by typing the following command:

```
ls -l /dev/ttyS?
```

The following should be displayed:

```
luchini@lcls-highbay $ ls -l /dev/ttyS?  
crw----- 1 luchini uucp 4, 64 Aug 29 19:06 /dev/ttyS0  
crw----- 1 luchini uucp 4, 65 Jun 24 2004 /dev/ttyS1  
crw-rw---- 1 root uucp 4, 66 Jun 24 2004 /dev/ttyS2  
crw-rw---- 1 root uucp 4, 67 Jun 24 2004 /dev/ttyS3  
crw-rw---- 1 root uucp 4, 68 Jun 24 2004 /dev/ttyS4  
crw-rw---- 1 root uucp 4, 69 Jun 24 2004 /dev/ttyS5  
crw-rw---- 1 root uucp 4, 70 Jun 24 2004 /dev/ttyS6  
crw-rw---- 1 root uucp 4, 71 Jun 24 2004 /dev/ttyS7  
crw-rw---- 1 root uucp 4, 72 Jun 24 2004 /dev/ttyS8  
crw-rw---- 1 root uucp 4, 73 Jun 24 2004 /dev/ttyS9
```

You should see you're account as the owner of **ttyS0** and **ttyS1**. In the example "luchini" has logged in and so "luchini" is the owner of **/dev/ttyS0** and **/dev/ttyS1**. The privilege for these devices need to also be set to 0660, which is specified in the file **/etc/security/console.perms**.

3) Verify that the global files **/etc/minirc._dev_ttyS0** and **/etc/minirc._dev_ttyS1** exist and are accessible from your linux-host.