Local Offline

Local Offline Overview

The local offline processes LDF into digi and uses calibrations that are installed in the SLAC database to produce reconstructed and high level data analysis files. The goal is to have a way to quick debug and characterize the beam during the set-up. If there is a copy of the database locally then we can use it to process events even when the connection to SLAC is down.

There will also be an offline monitoring running locally.

Computer names in the PS area

Cern is filtering ports below 1024! sshd is running on port 22 by default. I was setting it on 2222 temporarily, but this was not appreciated. Hence, the computers are not accessible from outside CERN.

"Socket-Gleam" PC: name pcglast37.cern.ch, IP 137.138.66.137, username online, password **(ask somebody!). Intended for online analysis using socket-Gleam. BeamtestRelease installations are found in /data/users/online/builds. The latest build is *BR v4r0909p3 in /data/users /online/builds/BeamtestRelease-v4r0909p3-rh9_gcc32opt. For detailed instructions on how to use GLAST software, check the workbook (link?). Here, a quick list only to analyze data:

- source /data/users/online/builds/BeamtestRelease-v4r0909p3-rh9_gcc32opt/BeamtestRelease/v4r0909p3/cmt/setup.sh
- In -s /pathToDataDir/nameOfLdfFile.ldf file.ldf
- \$GLEAMROOT/\$CMTCONFIG/Gleam.exe \$BEAMTEST06ROOT/jobOptions/ldf2digi.txt
- \$GLEAMROOT/\$CMTCONFIG/Gleam.exe \$BEAMTEST06ROOT/jobOptions/readigi_runrecon.txt

With some luck, you should have digi.root, recon.root, merit.root, and calTuple.root. For creating the beamtest tuple, check \$BEAMTESTTUPLEROOT/src /envVarOptions.dat. Set the appropriate env variables, and execute:

 \$BEAMTESTTUPLEROOT/\$CMTCONFIG/RunRootAnalyzer.exe \$BEAMTESTTUPLEROOT/srv/envVarOptions.txt For updating the calibration database description and the external libraries, there is a simple script ~online/bin/syncWithSLAC. It asks for your SLAC afs user name and password, runs rsync, and destroys the afs token again.

"Data-server" PC: name pcglast30.cern.ch, IP 137.138.66.138, username online, password *** (ask somebody!). Has ca. 500GB disk space. Doesn't have a monitor. Intended as data server only. Should store the root files produced in the SLAC pipeline. We need a concept how to do it.

Policy for updating calibration Database

Describes policy and steps for updating. When things become stable we will have a CCB.

Policy for Reprocessing

Describes policy and steps for reprocessing. When things become stable we will have a CCB.

Environmental Variables for Database

Setting up the environment so that one can acess the ORACLE database

Source /u/gl/glast/pdb_config/dpf_config_prod.csh (or .sh if you use BASH) to run the pipeline text-mode management tools, which are installed in \$PDB_HOME (which is set by the config script).

How to install mySQL as a server

From Leon and is currently udner review by Joanne (Jul 25 2006)

How to install MySQL as as server on your own (Windows) machine, install a local copy of the database, and get Gleam running without a network connection: (Disclaimer: I did all this as a rank novice, so there are probably better ways to do some of these things. But I think they will all work.)

1) Download the binary from www.mysql.com/downloads. You want mysql 3.23.56 (was in April 2003, anyway)

2) Unzip the file into a temporary directory.

3) Run setup.exe; install into the default directory (usually c:\mysql). Add c:\mysql\bin, for example, your path.

4) Write a file called my.cnf (using notepad, for example) containing the following lines:mysqld basedir=c:/mysql datadir=c:/mysql/data and put it in the root directory of your boot drive (c: in our case)

5) Install the server service, and start it:cd c:\mysql\bin >mysqld --install >NET Start MySQL (I believe that the server will restart at each subsequent boot.) See http://www.slac.stanford.edu/exp/glast/ground/software/calibration/docs/mysqlDirect.shtml for some examples.

7) Import the calibration database:

Move the file to your machine (ftp, mounted disk, whatever; it's an ascii file) and read it back:>mysql -u root mysql> create database calib; mysql> \q mysql calib < mydumpfile.sql mysql> use calib Database changed mysql> show tables;

Tables_in_cali b

junk
metadata_v0
metadata_v1
metadata_v2
metadata_v2r 1

5 rows in set (0.00 sec) 8) Set up users and passwords:

In order for Gleam to work, you need a glastreader user. Set it up as follows:> mysql -u root

mysql> grant usage on . to glastreader@localhost identified by 'glastpassword'; mysql> grant select on calib.* to glastreader@localhost identified by 'glastpassword'; (and maybe...)

mysql> grant usage on . to glastreader@"%" identified by 'glastpassword';

mysql> grant select on calib.* to glastreader@"%" identified by 'glastpassword';

mysql> select host, user, password from mysql.user;

<u>____</u>_____

hos	use	passwor
t	r	d

<u>____</u>_____

localhos t	root	
%	root	
localhos t		
%		
%	glastreade r	****
localhos t	glastreade r	****

6 rows in set (0.00 sec)

'xxxx...' is the encrypted form of the password you just typed in... Actually, it's not 'xxxx...' but I x'ed it out so you wouldn't see it. It's what MySQL uses to check the plaintext password. The password 'glastpassword' is the same one that you got from Leon or Joanne, above.

You also want to protect your 'root' user with a password:mysql>set password for root@localhost = password('mynewpassword'); Query OK...

mysql> set password for root@"%" = password('mynewpassword');

Query OK...

mysql> select host, user, password from mysql.user;

hos	use	passwor
t	r	d

localhos t	root	*****
%	root	****
localhos t		
%		
%	glastreade r	****
localhos t	glastreade r	****

6 rows in set (0.00 sec)

The "password('mynewpassword')" is very important... it does the encryption. If you leave it out, mysql> set password for root@"%" = 'mynewpassword'; ok...

it doesn't get encrypted, and MySQL won't recognize it when you try to login.

Finally, if you see a blank user, you should get rid of it:mysql%gt delete from mysql.user where host='localhost' and user="";

Query OK... mysql%gt delete from mysql.user where host="&" and user="";

Query OK...

mysql> select host, user, password from mysql.user;

hos use passwor t r d

localhos t	root	4e6064b31f46ea95
%	root	4e6064b31f46ea95
%	glastreade r	03559aa07ca5000 6
localhos t	glastreade r	03559aa07ca5000 6

4 rows in set (0.00 sec)

That's better!

9) Copy enough calibration files to satisfy Gleam:

Not a problem for now, since all the necessary files are in cvs, hence in calibUtil.

10) Modify the requirements file in calibUtil to point to the local database. (This will be handled from the jobOptions file eventually.):set MYSQL_HOST localhost

set MYSQL_METATABLE metadata_v2r1 10) Push the button!